



- ❶ Pile head waterproofing: Clean pile head thoroughly, then apply PENETRON® slurry to joint surfaces at $1.4\text{--}1.6 \text{ kg/m}^2$ ($2.5\text{--}3.0 \text{ lbs/y}^2$).
- ❷ Slab waterproofing: Apply PENETRON® slurry on the surface of lean concrete in 2 coats at $1.4\text{--}1.6 \text{ kg/m}^2$ ($2.5\text{--}3.0 \text{ lbs/y}^2$) in total.

Notes:

- PENETRON® waterproofing coating should be continuous between lean concrete and pile head.
- Schematic diagram shows PENETRON® application only and does not depict the standard requirements for waterstops or expansion joint sealant.