



- ❶ Joints waterproofing: According to Construction Joint Detail – Walls or Slabs.
- ❷ PENECRETE™ application: Apply PENECRETE™ in a mortar consistency to structural corners.
- ❸ PENETRON® slurry application: Apply PENETRON® slurry on the surface of wall and slab as indicated in 2 coats at $1.4\text{--}1.6\text{ kg/m}^2$ ($2.5\text{--}3.0\text{ lbs/y}^2$) in total.

Notes: • Schematic diagram shows PENETRON® application only and does not depict the standard requirements for waterstops or expansion joint sealant.